

### User Instruction:

1. Insert the transmitter with USB port of your computer, the built-in loudspeaker of the USB transmitter will tell the current frequency.
2. When using the USB transmitter with the computer for the first time, the computer will automatically install a driver. It can use the default driver of WIN7/WIN8/WIN XP/VISTA systems.
3. Press the "+" or "-" button on the USB transmitter to adjust frequency by 0.1mhz stepping, the loudspeaker will broadcast the current frequency after every press. Press and hold the "+" or "-" button for over 1second, the frequency will change by 1mhz each time, the loudspeaker will broadcast the Integer value of frequency.
4. Tune your radio receiver to the frequency that broadcasts from the USB transmitter. Please make sure this frequency is not occupied by other radio stations.
5. Open the audio properties in your computer, select USB device as the audio play device. Next time when you insert the USB transmitter again, it will switching to USB audio play mode automatically.
6. Open the media player in computer. If it is already opened before inserting USB transmitter, please close that and re-open.
7. Play audio source in computer, adjust system volume and line out volume to around 50%, the radio will receive the audio plays in computer. Then adjust the volume to get the best audio effect.
8. The USB transmitter has memory for broadcast frequency, next time it will automatically broadcast at the frequency that used last time.